




***7450.1210***

Onderdelen informatie  
Erzatzteil information  
Spare part information  
Information de pièces







POS:	Art.No.:	Omschrijving:	Aantal:
1		cabinet	1
2		door	1
3	CS9338.3345	door gasket	1
4	CS9338.3075	spring hinge	1
5	CS9338.3765	right upper hinge	1
6	CS9338.3520	eva. sensor	1
7	CS9344.0105	light/fan switch	1
8	CS9338.3570	power switch	1
9	CS9338.3550	controller	1
10	CS9338.3675	light cover	1
11	CS9338.3562	LED light	1
12		light box	1
13	CS9338.3115	door lock	1
14	CS9338.3065	panel	1
15		motor board	1
16	CS9338.3040	eva. fan cover	1
17		eva. fan blade	1
18	CS9338.3620	eva. fan	1
19	CS9338.3185	capillary	1
20	CS9338.3370	dryer filter	1
21	CS9338.3470	condenser	1
22	CS9338.3590	cond.fan cover	1
23		cond. Fan blade	1
24	CS9338.3600	cond. Fan motor	1
25	CS9390.2435	compressor	1
26		cooling unit board	1
27		sensor clip	1
28	CS9338.3525	sensor	1
29	CS9338.3790	outer drain pan	1
30	CS9338.3962	high pressure pipe	1
31	CS9338.3502	evaporator	1
32	CS9338.3716	heater	1
33		inner drain pan	1
34		fan plate	1
35		top cover	1
36	CS9338.3530	power cord	1
37		front shelf holder	2
38		M6 bolt	16
39	CS7950.5021	right shelf guide	10
40		feet(optional)	2
53	CS9338.3100	wheel(with lock)	2
41		feet(optional)	2
42	CS9338.3085	wheel	2

<b>POS:</b>	<b>Art.No.:</b>	<b>Omschrijving:</b>	<b>Aantal:</b>
43	CS9338.3902	right bottom hinge	1
44	CS9338.3900	hinge axis	1
45	CS9338.3280	door axis sleeve	1
46	CS9338.3250	cond. filter net	1
47	CS7950.5021	left shelf guide	10
48		panel connect	2
49		defrost heater clip	2
50		Upper Hinge Cover	1
51		back shelf holder	2