




**7455.1390**

**R290**

Onderdelen informatie  
Erzatzteil information  
Spare part information  
Information de pièces







POS:	Art.No.:	Omschrijving:	Aantal:
1	CS9338.1788	Right bottom hinge	1
2	CS9338.1978	Right glass door	1
3		Door support	1
4	CS9338.1847	Door lock	2
5		Lock card	2
6	CS9338.1977	Left glass door	1
7		Door sleeve	2
8	CS9338.1786	Left bottom hinge	1
9	CS9338.1594	Door seal	2
10		Central sill	1
11		Shelf strip	8
12	CS7455.1387	Right shelf	4
13	CS7455.1386	Left shelf	4
14	CS7455.1388	K clip	32
15.1	CS9338.1593	Front panel beam	1
15.2	CS9338.1593	Front panel middle beam	2
15.3	CS9338.1593	Lower beam of front panel	1
15.4	CS9338.1593	Left cover of front panel	1
15.5	CS9338.1593	Right cover of front panel	1
15.6	CS9338.1593	Rear cross member on front panel	1
16.1	CS9338.1592	Caster with brake	2
16.2	CS9338.1596	Caster without brake	2
17		Foot installed panel	2
18		Condenser	1
19		Water tray	1
20		Compressor installed panel	1
21		Condenser fan blade	1
22		Frost water pipe	1
23		Fan support	1
24		Dryer clip	1
25		Dry filter	1
26		Power cord	1
27		Compressor	1
28	CS9338.6004	High Efficiency Condenser fan	1
29		Back cover	1
30		Cabinet	1
31		Light cover(Right)	2
32	CS9338.1688	Left LED light	1
33		Light cover(Left)	2
34	CS9338.1686	Right LED light	1
35		Water pipe	1
36		Pipe cover	1
37	CS9338.1982	Evaporator	1

POS:	Art.No.:	Omschrijving:	Aantal:
38	CS7455.2320	Canopy left cover	1
39		Fan installed panel	1
40	CS7455.2320	Canopy bottom support	1
41	CS9338.2024	Canopy light	1
42	CS7455.2320	Canopy upper support	1
43	CS9338.6004	High Efficiency Evaporator fan	1
44		Fan motor support	1
45	CS7455.2320	Canopy cover support	2
46		Fan blade	1
47	CS7455.2320	Canopy left cover	1
48	CS9338.4140	Light switch	2
49		Fan cover	1
50	CS9338.6006	Operating model thermostat	1
53	CS7455.2320	Canopy plastic	1
54	CS9338.1786	Left bottom hinge	1
55		Door sleeve	2
56	CS9338.1788	Right bottom hinge	1