




**7455.1600**

Onderdelen informatie  
Erzatzteil information  
Spare part information  
Information de pièces







POS:	Art.No.:	Omschrijving:	Aantal:
1		Back housing cover	1
2		Screw for back houding cover	6
3		Screw	1
4		Gear	2
5		Bracket	2
6		Axle	1
7		Nut	2
8		Washer	2
9		Spring washer	2
10		Guide bar counterweight	2
11		Rubber washer	2
12		Rubber stud	2
13		Glider	2
14		Bushing	4
15		Bracket	2
16		Counterweight	1
17		Bracket	1
18		Bolt	1
19		Chain	1
20		Suspension bracket	1
21		Nut	2
22		Screw	1
23		Bracket for chain	1
24		Bolt	1
25		Spring washer	1
26		Washer	1
27		Bracket	1
28		Terminal bracket	1
29		Screw	4
30		Insulation plate	1
31		Axle pin	2
32		Nut	1
33		Spring washer	1
34		Screw	1
35		Washer	1
36		Pulley	1
37		Spring washer	1
38		Nut	1
39		Guide rail	2
40		Bearing	2
41		Spring tread tube	2
42		Nut	1
43		Spring washer	1

POS:	Art.No.:	Omschrijving:	Aantal:
44		Bracket	1
45		Bracket	1
46		Bolt	1
47		Nut	1
48		Ring	2
49		Axle	1
50		Bearing	2
51	9392.0830	Power cord	1
52		Cord inlet with retention	1
53		PE connector screw	1
54		PE connector washer	1
55		PE connector screw	1
56		Insulation plate	1
57		Wire jacket	1
58		Insulation cover plate	1
59		Insulation cover plate	1
60		Nut	8
61		Bracket	1
62		Bolt	4
63		Foot	4
64		Bottom housing cover	1
65		Bottom housing cover screw	6
66	9162.5310	Energy regulator	1
67	9344.0000	Indicator light (orange)	1
68	9344.0010	Indicator light (green)	1
69		Housing	1
70		Housing (back)	1
71		Washer	2
72		Drip tray	1
73		Grid	1
74		Upper housing cover	1
75		Screw	4
76		Insulation cover plate	1
77		Upper housing	1
78		Porcelain bracket	2
79		Handle	1
80		Screw for handle	2
81		Bracket (front)	1
82		Bracket (back)	1
83		Heating element clip	2
84	9343.0145	Heating element	1
85		Nut	2
86		Support	1



## Onderdelenlijst 7455.1600

POS:	Art.No.:	Omschrijving:	Aantal:
87		Cotter pin	2
88		Screw	2
89		Knob	1
90		Base plate with graduation ring	1