





**7950.5225**

**R290**

Onderdelen informatie  
Erzatsteil information  
Spare part information  
Information de pièces







POS:	Art.No.:	Omschrijving:	Aantal:
1		cabinet	1
2	CS9338.3905	right upper hinge	2
3	CS9338.3350	door gasket	3
4	CS9338.3910	right bottom hinge	2
5	CS9338.3755	door(right )	2
6	CS9338.3920	left bottom hinge	1
7	CS9338.3080	spring hinge	3
8	CS9338.3780	door(left )	1
9	CS9338.3275	door axis sleeve	5
10	CS9338.3915	left upper hinge	1
11		middle beam	2
12		middle beam connect	4
13		air guide board	1
14		left shelf guide	3
15		shelf	3
16		right shelf guide	3
17		beam hang strip(left)	3
18		rear hang strip(left)	3
19		beam hang strip(right)	3
20		rear hang strip(right)	3
21		fan cover	1
22		counter top	1
23		top fixing plate	4
24	CS9338.3515	probe	1
25		probe cover	1
26		eva. Fan cover	1
27	CS9338.3540	eva. Fan	1
28	CS9338.3775	evaporator	1
29	CS9338.3785	evapotaror drain pan	1
30		back cover	1
31	CS9338.3530	power cord	1
32	CS9390.2440	compressor	1
33	CS9338.3960	high pressure pipe	1
34	CS9338.3225	outer drain pan	1
35	CS9338.3615	cond. Fan motor	1
36	CS9338.3215	cond. Fan blade	1
37	CS9338.3585	cond.fan cover	1
38	CS9338.3450	condenser	1
39	CS9338.3370	dryer filter	1
40	CS9338.3190	capillary	1
41	CS9338.3260	dryer filter	1
42		cooling unit board	1
43	CS9338.3925	control panel upper hinge	1

POS:	Art.No.:	Omschrijving:	Aantal:
44	CS9338.3930	plastic water-proof box	1
45	CS9338.3935	plastic water-proof box cover	1
46	CS9338.3940	control paner bottom hinge	1
47		panel	1
48	CS9344.0105	power switch	1
49	CS9338.3545	controller	1
50	CS9338.3115	door lock	1
51		wheel	2
52	CS9338.3325	feet(optional)	2
53		wheel(with lock)	2
54	CS9338.3325	feet(optional)	2