











Machine	Explode	Code	Description
Dynamix mixer	0550	AE035	EMULSIFYING BLADE
Dynamix mixer	0551	AE036	STANDARD BLADE WITH SCREWS
Dynamix mixer	0552	AE037	BATTER BLADE WITH SCREWS
Dynamix mixer	0553	AE038	SMOOTHIE EMULSIFYING BLADE WITH SCREWS
Dynamix mixer	079958	AD511	COVER OR HANDLE SCREWS (2)
Dynamix mixer	2840	☎	COVER
Dynamix mixer	2841	☎	HOOK
Dynamix mixer	2842	☎	POWER CORD 230V
Dynamix mixer	2842.1	☎	POWER CORD 115V
Dynamix mixer	2843	☎	RIGHT HANDLE
Dynamix mixer	2844	AD507	SHAFT AND BEARING
Dynamix mixer	2845	AD510	DYNAMIX FOOT ASSEMBLY + RING + SEAL
Dynamix mixer	2846	AD508	COUPLING
Dynamix mixer	2847	AB743	MOTOR 230V
Dynamix mixer	2847.1	☎	MOTOR 115V
Dynamix mixer	2848	☎	DYNAMIX LABEL
Dynamix mixer	2849	☎	LEFT HANDLE
Dynamix mixer	2850	☎	SCREWS + WASHER + HANDLE NUTS (2)
Dynamix mixer	2851	☎	HOOD
Dynamix mixer	2852	☎	CIRCUIT BOARD 230V
Dynamix mixer	0744	☎	PIN 3 X 20

Machine	Explode	Code	Description
Dynamix mixer	2852.1		CIRCUIT BOARD 115V
Dynamix mixer	2853		ID LABEL (230V)
Dynamix mixer	2853.1		ID LABEL (115V)
Dynamix mixer	2854		MOTOR BELT
Dynamix mixer	2855		SCREWS FOR MOTOR BELT (2)
Dynamix mixer	2858		VARIATOR KNOB
Dynamix mixer	2859		DRIVING SHAFT JOINT
Dynamix mixer	2860		COUPLING HUB
Dynamix mixer	2861		STRAIN RELIEF 230 V
Dynamix mixer	2861.1		STRAIN RELIEF 115 V
Dynamix mixer	45710	AD526	HANDLE CAP PROTECTORS
Dynamix mixer	-	-	COMPLETE FOOT (SEE MACHINE CATALOGUE)