





Machine	Explode	Code	Description
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	0504	AD505	CARBON BRUSHES (2)
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	0601	AD504	BALL BEARING
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	0607		WATERPROOF SEAL
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	0726	AC148	SQUEEZING WASHER
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	0862		WALL BRACKET
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	0950		STRAIN RELIEF 230 V
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	0950.1		STRAIN RELIEF 115 V
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	1017		WARNING LABEL
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	1021		DYNAMIC LABEL
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	1097		ID LABEL 115 V
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	1099.15		ID LABEL 230 V
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	2001		CONTROL LEVER
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	2002	AD551	SAFETY CONTROL LEVER
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	2003DSC		230 V ELECTRONIC CIRCUIT (VARIATOR + REGULATOR CIRCUIT + CONTROL CIRCUIT)
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	2003.1DSC		115 V ELECTRONIC CIRCUIT (VARIATOR + REGULATOR CIRCUIT + CONTROL CIRCUIT)
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	2004		UPPER HALF HANDLE (BUTTON SIDE)

Mx 2000 dsc 230 / 115 v – 50 / 60 hz	2005		UPPER HALF HANDLE (LABEL SIDE)
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	2006DSC		MOTOR HOUSING BRUSH HOLDER
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	2007		COMPLETE FOOT ASSEMBLY
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	2009		FOOT ASSEMBLY
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	2001DSC		STATOR 230 V
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	2011.1DSC		STATOR 115 V
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	2012		POWER CORD 230 V
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	2012.1		POWER CORD 115 V
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	2012.2	AD552	POWER CORD (ENGLISH)
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	2012.3		POWER CORD (AUSTRALIAN)
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	2021		VARIABLE SPEED CONTROL BUTTON
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	2060		COMPLETE HANDLE 230 V
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	2060.1		COMPLETE HANDLE 115 V
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	2061		SENSORING WASHER (WASHERS, MAGNETS, SCREWS, SMALL BRACE)
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	7903		BRACE SCREWS (4)
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	7910		EMULSIFYING BLADE
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	7916	AD503	LOWER MOTOR CASING
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	7917	AD501	BRACE SCREWS (4)
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	7933		FAN
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	9008.11DSC		ROTOR 115 V
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	9008.12DSC	AD553	ROTOR 230 V
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	9014		HANDLE SCREWS (4)
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	9023		FIELD BRACE SCREWS (2)
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	9025	AB748	MOTOR BALL BEARING SLEEVE
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	9026		BRACES
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	9043		CARBON BRUSH WIRES (2) (230 V)
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	9131	AD502	FITTED SHAFT
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	9143		CARBON BRUSH WIRES (2) (115 V)
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	9164	AD548	SHAFT, LOWER BALL BEARING & CUTTER ASSEMBLY
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	9902		POWER BEARING SCREWS (3)
Mx 2000 dsc 230 / 115 v – 50 / 60 hz	45710	AD526	SAFETY COVER