













Exploded diagram and spare parts list



Machine	Explode	Code	Description
FC255 - Buffalo Single Fryer - 3Ltr	1		Triangle Plate
FC255 - Buffalo Single Fryer - 3Ltr	2	N117	Breaker
FC255 - Buffalo Single Fryer - 3Ltr	3	N280	Heating Element
FC255 - Buffalo Single Fryer - 3Ltr	4		Gasket
FC255 - Buffalo Single Fryer - 3Ltr	5	AH342	Switch
FC255 - Buffalo Single Fryer - 3Ltr	6	N279	Drip Tray Assy
FC255 - Buffalo Single Fryer - 3Ltr	7	AD585	Indicator Light
FC255 - Buffalo Single Fryer - 3Ltr	8	N116	Thermostat
FC255 - Buffalo Single Fryer - 3Ltr	9	N152	Feet
FC255 - Buffalo Single Fryer - 3Ltr	10	AK361	Knob
FC255 - Buffalo Single Fryer - 3Ltr	11		Stuffing Nut
FC255 - Buffalo Single Fryer - 3Ltr	12	N282	Basket
FC255 - Buffalo Single Fryer - 3Ltr	13		Electrical Box Assy.
FC255 - Buffalo Single Fryer - 3Ltr	14		Electrical Box Assembly
FC255 - Buffalo Single Fryer - 3Ltr	15		Handle
FC255 - Buffalo Single Fryer - 3Ltr	16	AC841	Cover Assembly
FC255 - Buffalo Single Fryer - 3Ltr	17		Main Body Assy.
FC255 - Buffalo Single Fryer - 3Ltr	18	AH040	Switch
FC255 - Buffalo Single Fryer - 3Ltr	19		Bushing
FC255 - Buffalo Single Fryer - 3Ltr	20		Teflon Stick
FC255 - Buffalo Single Fryer - 3Ltr	21		Baffle Assy
FC255 - Buffalo Single Fryer - 3Ltr	22		Power Cord