








































Machine	Explode	Code	Description
GE769 - Polar G-Series Triple Door Display Refrigerator	1		Body
GE769 - Polar G-Series Triple Door Display Refrigerator	2		Connecting Wire
GE769 - Polar G-Series Triple Door Display Refrigerator	3	AM008	Power Cord
GE769 - Polar G-Series Triple Door Display Refrigerator	4		Machine Room Cover
GE769 - Polar G-Series Triple Door Display Refrigerator	5		Machine Room Supporter
GE769 - Polar G-Series Triple Door Display Refrigerator	6	AL236	Compressor (R290)
GE769 - Polar G-Series Triple Door Display Refrigerator	7		Evaporator Tube Right
GE769 - Polar G-Series Triple Door Display Refrigerator	7		Evaporator Tube Left
GE769 - Polar G-Series Triple Door Display Refrigerator	8	AK833	Water Tray
GE769 - Polar G-Series Triple Door Display Refrigerator	9	AK835	Filter Clip
GE769 - Polar G-Series Triple Door Display Refrigerator	10	AK834	Filter Drier
GE769 - Polar G-Series Triple Door Display Refrigerator	11		Install Plate of Wheels
GE769 - Polar G-Series Triple Door Display Refrigerator	12	AK880	Condenser Fan Motor & Blade
GE769 - Polar G-Series Triple Door Display Refrigerator	13		Condenser Fan Motor Cover
GE769 - Polar G-Series Triple Door Display Refrigerator	14		Condenser
GE769 - Polar G-Series Triple Door Display Refrigerator	15	AK837	Standard & Braked Castors (set 6)
GE769 - Polar G-Series Triple Door Display Refrigerator	16		Bottom Fixing Plate
GE769 - Polar G-Series Triple Door Display Refrigerator	17		Cabinet Middle Supporter Declaration
GE769 - Polar G-Series Triple Door Display Refrigerator	18		Cabinet Middle Supporter
GE769 - Polar G-Series Triple Door Display Refrigerator	19		Connecting Wires
GE769 - Polar G-Series Triple Door Display Refrigerator	20	AN646	Lower Front Panel
GE769 - Polar G-Series Triple Door Display Refrigerator	21	AK822	Door Hinge Left
GE769 - Polar G-Series Triple Door Display Refrigerator	22	AN991	Right / Left Shelf
GE769 - Polar G-Series Triple Door Display Refrigerator	23	AN992	Middle Shelf
GE769 - Polar G-Series Triple Door Display Refrigerator	24	AK881	Thermostat Sensor
GE769 - Polar G-Series Triple Door Display Refrigerator	25	AK862	Digital Controller
GE769 - Polar G-Series Triple Door Display Refrigerator	26		Door Supporter for Door Right
GE769 - Polar G-Series Triple Door Display Refrigerator	27		Door Supporter for Door Left
GE769 - Polar G-Series Triple Door Display Refrigerator	28	AK824	Door Hinge Right
GE769 - Polar G-Series Triple Door Display Refrigerator	29		Junction Box
GE769 - Polar G-Series Triple Door Display Refrigerator	30	AK842	Shelf Support
GE769 - Polar G-Series Triple Door Display Refrigerator	31	AK843	Shelf Clip (set 4)
GE769 - Polar G-Series Triple Door Display Refrigerator	32		Tube Cover
GE769 - Polar G-Series Triple Door Display Refrigerator	33		LED Left (Red Label)
GE769 - Polar G-Series Triple Door Display Refrigerator	34		LED Right (White Label)
GE769 - Polar G-Series Triple Door Display Refrigerator	35		Upper Hinge Left
GE769 - Polar G-Series Triple Door Display Refrigerator	36		Inner LED Light (Short Line)
GE769 - Polar G-Series Triple Door Display Refrigerator	37		Canopy LED Light (Long Line)
GE769 - Polar G-Series Triple Door Display Refrigerator	38		Upper Hinge Right
GE769 - Polar G-Series Triple Door Display Refrigerator	39	AL237	LED Transformer
GE769 - Polar G-Series Triple Door Display Refrigerator	40		Canopy Side Cover Left
GE769 - Polar G-Series Triple Door Display Refrigerator	41		Upper Canopy Cover
GE769 - Polar G-Series Triple Door Display Refrigerator	42	AK860	Light Switch
GE769 - Polar G-Series Triple Door Display Refrigerator	43		Canopy Side Cover Right
GE769 - Polar G-Series Triple Door Display Refrigerator	44		Canopy Side Support

GE769 - Polar G-Series Triple Door Display Refrigerator	45		Canopy Cover
GE769 - Polar G-Series Triple Door Display Refrigerator	46		Lower Canopy Cover
GE769 - Polar G-Series Triple Door Display Refrigerator	47		Evaporator Supporter
GE769 - Polar G-Series Triple Door Display Refrigerator	48		Evaporator
GE769 - Polar G-Series Triple Door Display Refrigerator	49		Fan Cover
GE769 - Polar G-Series Triple Door Display Refrigerator	50		Evaporator Fan Support
GE769 - Polar G-Series Triple Door Display Refrigerator	51	AK853	Evaporator Fan & Blade
GE769 - Polar G-Series Triple Door Display Refrigerator	52		Evaporator Fan Cover
GE769 - Polar G-Series Triple Door Display Refrigerator	53		Right / Left Price Tag
GE769 - Polar G-Series Triple Door Display Refrigerator	54		Middle Price Tag
GE769 - Polar G-Series Triple Door Display Refrigerator	55		Door Seal
GE769 - Polar G-Series Triple Door Display Refrigerator	56		Door Right
GE769 - Polar G-Series Triple Door Display Refrigerator	57		Door Left
GE769 - Polar G-Series Triple Door Display Refrigerator	58	AK874	Handle
GE769 - Polar G-Series Triple Door Display Refrigerator	59	AK876	Lock & Key
GE769 - Polar G-Series Triple Door Display Refrigerator	N/A	AP233	Tie