

L792 PRO CLIP-ON TORCH HEAD WITH HANDLE

Category: direct pressure appliance.

This appliance shall only be used with threaded valve type butane cartridge according to bayonet type.

This burner is for culinary use only.

① GENERAL SAFETY RULES:

1. Read the follow operating instructions and cautions and familiarize yourself with the torch before lighting or using. Review instructions and cautions periodically to maintain awareness. Do not try to operate before reading instructions.
2. Do not point torch towards face, other persons or flammable objects. Never attempt to use torch as a cigarette lighter.
3. Disconnect cylinder when not in use.
4. Never attempt to modify the torch construction and never use unapproved fuels.
5. Treat the torch as you would with any fire tool or instrument. Do not drop or otherwise abuse.
6. Do not use a leaking, damaged or malfunctioning torch.
7. Work only in well-ventilated areas.
8. This burner should only be used with food.
9. Always place your work on firebrick. If you are not sure it is firebrick, do not use it. Ordinary brick and concrete can explode when subjected to high temperatures. Do not work on wood or metal surfaces. Always shield your work.
10. Always wear protective gloves and use proper tools to handle hot work.
11. Be aware that the tip of the torch can get extremely hot during use. Take precautions to protect yourself and others from accidental burns. Never use the torch on or near combustibles. Be especially careful around motor vehicles or any gasoline-fired products and beware of hidden fuel lines and tanks.
12. Always make certain the torch is placed on a level surface when connected to the fuel cylinder to reduce the risk of accidental tip over. Be sure torch is not pointed in a direction which could cause nearby objects to ignite when torch is set down.
13. Always have a fire extinguisher and a suitable fire extinguishing equipment near the torch and work area. Do not place them in the flame path or in a location where you could not reach them should a fire break out.

INSTRUCTIONS

② ASSEMBLY:

- Make sure valve is OFF by turning knob in direction of arrow until hand tight only. DO NOT FORCE.
- Turn fuel cylinder clockwise into valve body until hand tight. DO NOT FORCE. (as shown below)

③ OPERATION AND LIGHTING:

- Use only high quality Butane gas cylinder.
- Make sure the on/off adjustment knob is in "OFF" position.
- Shake gas cylinder a few times to warm the fuel up.
- Turn the adjustment knob counterclockwise for 2/3 of a circle. The gas will blow out with a "HISS" sound from the burner nozzle. (Fig. 1&2)
- Press "IGNITION BUTTON" and the flame will ignite instantly.

④ TEMPERATURE ADJUSTMENT:

- For hottest, most efficient, adjust inner blue flame of pencil burner to 38mm~50mm in Length.

⑤ TURNING OFF AND STORAGE:

REMOVE CYLINDER FROM TORCH WHEN NOT IN USE.

- Turn valve off.
- When torch is cool, turn fuel cylinder counter clockwise from valve body to disconnect. (Fig. 3&4). Then store torch and cylinder separately. Observe cautions on cylinder label.

⑥ WARNING:

1. The cylinder contains Butane.
If the torch is moved rapidly, tilted too far to the side or upside down, the liquid can enter the valve and cause the flame to flare or extinguish. To prevent this adjust the torch to a 1/4" long inner flame and let the torch warm up for 3 minutes, prior to such movement. Then slowly readjust as necessary once the torch is in desired operating position.
2. Make sure torch is cool before tightening or removing burner head, or before installing or removing accessories.
3. Cold weather operation
 - a.) In cold weather the size of the flame will be smaller. To produce a larger flame, the appliance should be allowed to adjust to room temperature prior to use, to produce a larger flame.
 - b.) There is a greater possibility that the flame will extinguish when the torch is turned upside down in cold weather.

VOGUE

⑦ DANGER:

EXTREMELY FLAMMABLE. CONTENTS UNDER PRESSURE. Keep away from heat or flame. It is illegal and dangerous to refill the cylinder. Obtain new cylinder from your dealer. Keep out of reach of children. Avoid prolonged exposure to sunlight. Do not store near heat or in a room used for habitation. Always close burner valve and wait at least 30 seconds before removing burner from cylinder. Always detach cylinder from burner when not in use. Do not breathe gas, fumes, vapour or spray. If inhaled, move affected person to a place with fresh air. Avoid contact with skin and eyes. For skin contact, flush with large amounts of water. In case of contact with eyes, rinse immediately with plenty of water and seek medical advice. When cylinder is empty, discard in a safe place. Do not throw in fire. Do not puncture or incinerate container.



Fig.1



Fig.2



Fig.3



Fig.4

