



CUBE EC1 CONVECTION OVEN

Onderdelen informatie


Erzatzteil information

Spare part information

Information de pièces



CUBE EC1 CONVECTION OVEN



Onderdelenlijst CUBE EC1 CONVECTION OVEN

POS:	Art.No.:	Omschrijving:	Aantal:
1		LOWER BEAM (DOOR)	
2	9341.0485	EXTERNAL TOUGHENED GLASS	1
3		SCREW	
4		DOOR POST	
5	9341.0470	DOOR HINGE	2
6		SCREW	
7	9113.1090	HANDLE END	2
8	9341.0490	INTERNAL GLASS (DOOR)	1
9		SELF-TAPPING SCREW	
10	9341.0425	THERMOSTAT KNOB	1
11	9341.0460	KNOB BASE	1
12	9341.0440	TIMER INDICATOR	1
13	9341.0445	POWER INDICATOR	1
14	9341.0430	TIMER KNOB	1
15	9341.0420	BASE SHEET (KNOB)	1
16		LOWER FRONT PANEL	
17		BASEBOARD	
18	9341.0435	TIMER	1
19	9341.0480	LEG	4
20		SCREW	
21		CORD SHEATH	
22		POWER CORD	
23	9341.0405	TEMP LIMITER	1
24		GROUND BOLT	
25	9341.0410	THERMOSTAT	1
26		BRACKET	
27		CHAMBER	
28	9341.0475	FIXED BRACKET (DOOR HINGE)	2
29		SCREW	
30		INSULATION COTTON (BACK)	
31		INSULATION COTTON (CHAMBER)	
32		HOUSING	
33		REAR SHROUDING	
34	9341.0400	MOTOR	2
35	9341.0465	DOOR SEAL	1
36	9341.0450	LAMP BASE + COVER	1
37	9341.0455	CHAMBER LAMP	1
38	9393.0064	LAMP COVER	1
39	9341.0415	HEATING ELEMENT	2
40		SET SCREW	
41	9341.0400	FAN BLADE	2
42		SET NUT	
43		AIR DEFLECTOR	
44		SHELF	
45		TOP BEAM (DOOR)	
46		HANDLE TUBE	
47		SET SCREW	